



INSTALLATION INSTRUCTIONS

These instructions are for right-hand swing open operation of the outer door. For left-hand swing open operation, attach the enclosure hardware to the opposite side.

STEP1: Installing the enclosure hardware

1. With the back box securely mounted, attach the outer door hinge pins to the mounting studs on the back box left flange.
2. Attach the door stops to the top and bottom mounting studs on the back box right flange.
3. Attach the lock striker plate to the middle mounting studs on the back box right flange.

STEP 2: Assembling the outer door


1. Place the outer door on a flat surface with the inside facing up.
2. Attach hinges to right mounting studs.
3. Insert the door lock through the opening opposite the hinges and with the latch pointing towards top of the door. See figure on other side.
4. Secure lock with the retaining clip.
5. Insert the plastic hole plug in the door opening closest to the hinges.

STEP 3: Mounting the outer door assembly

1. Set the outer door assembly onto the outer door hinge pins.
2. Attach the hinge stop to the outer door assembly.
3. Attach a grounding strap from the outer door ground strap stud on the back box to the outer door.

STEP 4: Mounting the inner door

1. Set the inner door onto the inner door hinge pins.
2. Attach a grounding strap from the inner door ground strap stud on the back box to the inner door.



PRODUCT DESCRIPTION

The 3-CAB series of equipment enclosure doors consists of an inner and outer door. The outer door may be mounted to either side of the back box for left-open or right-open operation, has a viewing window, and is secured with a key lock. A hinged interior door panel isolates the operator from the panel electronics and wiring, yet easily opens for maintenance.

The 3-CAB series of equipment enclosure doors include:

- | | |
|-----------|------------------------------------------|
| 3-CAB7D | Grey door w/window for CAB7B back boxes |
| 3-CAB7DR | Red door w/window for CAB7B back boxes |
| 3-CAB14D | Grey door w/window for CAB14B back boxes |
| 3-CAB14DR | Red door w/window for CAB14B back boxes |
| 3-CAB14D | Grey door w/window for CAB21B back boxes |
| 3-CAB14DR | Red door w/window for CAB21B back boxes |

INSTALLATION SHEET:

3-CAB Series Equipment Enclosure Doors

INSTALLATION SHEET P/N: 270488


FILE NAME: 270488.CDR

REVISION LEVEL: 3.0

DATE: 15AUG06




Inner Door Assembly



Outer Door Installation

Outer Door Assembly



	Female Hinges	Double Male Hinge	Lock	Plug
Left-hand Mounting	D & F	D	B Latch Up	E
Right-hand Mounting	A & C	A	E Latch Down	B

	Bumpers Plates	Lock Strike	Double Male Hinge Pin
Left-hand Mounting	D & F	E	C
Right-hand Mounting	A & C	B	F